



Intel-powered Convertible Classmate PC Quick Controller User Manual

For Ubuntu Netbook Remix Operating System

Disclaimer

INFORMATION IN THIS DOCUMENT IS PROVIDED IN CONNECTION WITH INTEL® PRODUCTS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT. EXCEPT AS PROVIDED IN INTEL'S TERMS AND CONDITIONS OF SALE FOR SUCH PRODUCTS, INTEL ASSUMES NO LIABILITY WHATSOEVER, AND INTEL DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATING TO SALE AND/OR USE OF INTEL PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

UNLESS OTHERWISE AGREED IN WRITING BY INTEL, THE INTEL PRODUCTS ARE NOT DESIGNED NOR INTENDED FOR ANY APPLICATION IN WHICH THE FAILURE OF THE INTEL PRODUCT COULD CREATE A SITUATION WHERE PERSONAL INJURY OR DEATH MAY OCCUR.

Intel may make changes to specifications and product descriptions at any time, without notice. Designers must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined." Intel reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them. The information here is subject to change without notice. Do not finalize a design with this information.

The products described in this document may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

Contact your local Intel Sales Office or your distributor to obtain the latest specifications and before placing your product order.

Intel and the Intel logo are trademarks of Intel Corporation in the U.S. and other countries.

Copyright © 2009, Intel Corporation.

All rights reserved.

*Other brands and names are the property of their respective owners.

Revision History

Document Revision	Revision History	Date
1.0	First release of Intel-powered convertible classmate PC Quick Controller User Manual.	January 2009

Table of Contents

1	Introduction	4
1.1	System Requirements.....	4
1.2	Install	5
1.3	Uninstall	5
1.4	Start Up.....	5
2	Features	6
2.1	Quick Controller Main Panel	6
2.2	Brightness Adjustment.....	7
2.3	Volume Control	7
2.3.1	Volume Adjustment	7
2.3.2	Mute/Un-Mute Switch.....	8
2.4	Switch Display	9
2.5	Calibrate Screen	9
2.6	Show/Hide Cursor	9
2.7	Screen Rotation	10
2.7.1	Auto Rotation	10
2.7.2	Manual Rotation	11
3	About	12
4	Exit.....	13
5	Frequently Asked Questions	14

Figures

Figure 1 - Quick Controller Main Panel 6

Figure 2 - Quick Controller Brightness Adjustment 7

Figure 3 - Quick Controller Volume Adjustment..... 8

Figure 4 - Mute Status 8

Figure 5 - Un-Mute Status 8

Figure 6 - Switch Display Button..... 9

Figure 7 - Calibrate Screen Button 9

Figure 8 - Show Cursor10

Figure 9 - Hide Cursor.....10

Figure 10 - Auto Rotation Mode10

Figure 11 - Manual Rotation Mode.....11

Figure 12 - About Dialog12

1 Introduction

Intel-powered convertible classmate PCs are affordable, rugged, fun netbooks built for learning. Based on research in educational settings, the child-friendly design converts from a clamshell to a touch-optimized tablet – promoting intuitive use, interactive learning, and new mobility. Intel-powered convertible classmate PCs come with education-specific features and software and are supported by a wide range of local vendors.

Quick Controller is a special control panel that provides the user a simple way to customize their computer. It can adjust LCD brightness, system volume, rotation, and launch some special system tools.

A summary of the features are listed below:

- Brightness Adjustment: Adjust LCD brightness
- Volume Control: Mute/Un-Mute, Volume adjustment
- Switch Display: Toggle among CMPC LCD only, Dual Display, and External Monitor Only modes
- Touch Screen Calibration: Launch touch screen tool to calibrate touch screen
- Show/Hide Cursor: Show/Hide system cursor
- Rotation: Auto/Manual rotation, it can rotation 90 and 180 degree

1.1 System Requirements

The system requires an Ubuntu operating system.

1.2 Install

The application can be installed by clicking the **DEB** install package. If an earlier version of the application is detected, a prompt will promote the user to upgrade it.

1.3 Uninstall

If you do not login as a Root account, run the following command:
sudo dpkg -r quick-controller.

1.4 Start Up

Click **Application** -> **Other** -> **Quick Controller** to launch the application or click the shortcut on the desktop. Double-clicking the Bezel button will also launch the application.

2 Features

2.1 Quick Controller Main Panel

The figure below shows the Quick Controller.



Figure 1 - Quick Controller Main Panel

2.2 Brightness Adjustment

System brightness can be adjusted by pressing the corresponding up/down button or directly clicking on the brightness bar of Quick Controller.



Figure 2 - Quick Controller Brightness Adjustment

2.3 Volume Control

You can adjust the volume level and mute or un-mute the volume through Quick Controller.

2.3.1 Volume Adjustment

The volume level can be adjusted by pressing the corresponding up/down button or directly clicking on the volume bar of Quick Controller.



Figure 3 - Quick Controller Volume Adjustment

2.3.2 Mute/Un-Mute Switch

Click the **Mute** button to mute or un-mute the volume.

When the checkbox in the **Mute** button is checked, then the current volume is muted.



Figure 4 - Mute Status

When the checkbox in the Mute button is unchecked, then the current volume is un-muted.



Figure 5 - Un-Mute Status

2.4 Switch Display

The display screen has three display modes: CMPC LCD only, Dual Display, and External Monitor Only. You can toggle among these three modes by clicking the **Switch Display** button.



Figure 6 - Switch Display Button

2.5 Calibrate Screen

The **Calibrate Screen** button launches the Screen Calibration tool.



Figure 7 - Calibrate Screen Button

2.6 Show/Hide Cursor



NOTE

*Under the clamshell mode, the **Show Cursor** function is disabled; but under tablet mode, the this function is enabled.*

Click the **Show Cursor** button to show or hide system cursor.

When the checkbox in Show Cursor button is checked, then the current system cursor is shown.




Figure 8 - Show Cursor

When the checkbox in Show Cursor button is unchecked, then the current system cursor is hidden.



Figure 9 - Hide Cursor

2.7 Screen Rotation

There are two screen rotation modes:

- Auto rotation
- Manual rotation

2.7.1 Auto Rotation

When the checkbox in **Auto Rotation** button is checked, the accelerometer will detect the orientation of the screen and the screen will be rotated automatically according to the orientation.



Figure 10 - Auto Rotation Mode

2.7.2 Manual Rotation

When the checkbox in **Auto Rotation** button is unchecked, the screen can be manually rotated clockwise or counterclockwise by 90 or 180 degrees by pressing the corresponding rotate button. Clicking the Auto Mode will switch to auto rotation mode.



Figure 11 - Manual Rotation Mode

3 About



The About window can be opened by clicking the  button on the Quick Controller. This window shows the product name, version, and copyright information.



Figure 12 - About Dialog

4 Exit

The application can be closed in three ways:

- Clicking the  button on the Quick Controller.
- Clicking any blank area of the screen.
- The application will automatically close after 15 seconds if no activity is detected by Quick Controller.

5 Frequently Asked Questions

Q: Why are some buttons in Quick Controller unusable?

A: Some related tools which Quick Controller uses are not installed on the computer.

Q: Why does Quick Controller exit when I am doing some other operations?

A: Quick Controller will exit when the panel is not active or if after 15 seconds there isn't any activity on the panel. The application can be restarted as mentioned in the *1.4 Startup* section.